



Ordering codes – Elastomer couplings




Note:

In case of different inner diameters of the clamping hubs, the respective larger one is to be defined as output D 2

Ordering codes – Elastomer couplings ELT




Ordering codes – Intermediate spacer




For information purposes only – not required when placing orders!
Please contact WITTENSTEIN alpha for deviating mounting positions.

Ordering codes – Metal bellows couplings




Note:
 In case of different inner diameters of the clamping hubs, the respective larger one is to be defined as output D 2

Ordering codes – Metal bellows couplings BCT




For information purposes only – not required when placing orders!
 Please contact WITTENSTEIN alpha for deviating mounting positions.

Ordering codes – Torque limiters



Ordering codes – Torque limiters TL1



For information purposes only – not required when placing orders!
Please contact WITTENSTEIN alpha for deviating mounting positions.